

CABINET PARTS

REFRIGERATOR

For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11


(White)

(Black)

(Stainless Steel)

(Bisque)

(Satina)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11

(White)

(Black)

(Stainless Steel)

(Bisque)

(Satina)

| Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|---------------------------------|------------|------------|----------------------------------|------------|------------|--------------------|
| 1 | | Literature Parts | 13 | A3076901 | Plug, Button | 23 | M0108105 | Clip, Water Line |
| | W10137645 | Owners Manual | 14 | 67006303 | Screw | 24 | B5705307 | Tube, Plastic |
| | W10179469 | Energy Tag | 15 | | Hinge, Center | 25 | 67006425 | Screw (10) |
| | W10165418 | Tech Sheet | | 67006960 | White | 26 | W10137519 | Elbow, Fill Tube |
| 2 | | Cabinet (Not a Servicable Part) | | 67007043 | Black | 27 | 67004611 | Cover, Water Valve |
| 3 | | Plug, Button (3) | 16 | 67003868 | Foot Brake | 28 | 12575101ED | Cover, Unit |
| | 67001130 | White | 17 | | Cover, Corner | 29 | 67003331 | Cover, Water Line |
| | 67001131 | Black | | 67003484 | White | 30 | 67003796 | Insulation, Sound |
| | M0310738 | Bisque | | 67003485 | Black | 31 | W10164397 | Tube, Drain |
| 4 | 67002816 | Clip, Water Line | | 67003486 | Bisque | 32 | 67001067 | Clip, Drain Tube |
| 5 | 67006118 | Roller Assembly | 18 | 12566604ED | Hinge, Top | 33 | M0286708 | Nut, Speed |
| 6 | 12627302 | Clip, Grille | 19 | 67007174 | Bracket, Foot | 34 | 67005127 | Roller |
| 7 | 67006642 | Pin, Center Hinge | 20 | 67006564 | Screw | 35 | M1205302 | Pin |
| 8 | 67006611 | Bolt, Adjusting (Rear) | 21 | | Cover, Hinge | 36 | 67006737 | Screw |
| 9 | 67006521 | Screw | | 67001014 | White | 37 | 67006287 | Screw |
| 10 | 12456801 | Bracket, Roller | | 67001012 | Black | 38 | B5759649 | Gasket |
| 11 | 67006380 | Screw (3) | | 67001013 | Bisque | 39 | 67004092 | Block, Filter |
| 12 | 67006473 | Screw | 22 | | Grille Assembly (Includes Clips) | | | |
| | | | | 67007004 | White | | | |
| | | | | 67006954 | Black | | | |
| | | | | 67006791 | Bisque | | | |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11


(White)

(Black)

(Stainless Steel)

(Bisque)

(Satina)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11
(White) (Black) (Stainless Steel) (Bisque) (Satina)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|--------------------------------|
| 1 | | Liner (Not A Serviceable Part) |
| 2 | Y67003896 | Bracket, Control and Lights |
| 3 | 67005190 | Overlay |
| 4 | W10185244 | Housing, Electronic Control |
| 5 | W10165748 | Board, Control |
| 6 | C3680310 | Switch, Light |
| 7 | 67003897 | Cover, Light |
| 8 | 67003901 | Housing, Light |
| 9 | A0282812 | Bulb, Light (2) |
| 10 | Y12570701 | Socket, Light (2) |
| 11 | 67003900 | Insert, Damper Cover |
| 12 | 67006602 | Screw |
| 13 | 67003899 | Cover, Damper |
| 14 | 67006604 | Insulation |
| 15 | W10127429 | Control, Damper |
| 16 | M0310343 | Plug, Button |
| 17 | 12002355 | Thermistor |
| 18 | 67001668 | Plate |
| 19 | W10153958 | Tank, Water |
| 20 | W10158503 | Dispenser |
| 21 | 67006400 | Screw |
| 22 | B8390302 | Clip |
| 23 | 67006524 | Housing, Filter Head |
| 24 | 12568001 | Cover, Filter |
| 25 | W10181835 | Filter, Water |
| 26 | 12664501 | Head, Filter Bypass |
| 27 | 67002742 | Plate, Switch |
| 28 | 67006287 | Screw |
| 29 | 67005674 | Cover |
| 30 | 12575501 | Switch, Limit |
| 31 | 61006182 | Union |
| 32 | 67002816 | Clip, Water |
| 33 | 67002743 | Guide, Water |

Following Parts Not Illustrated

67004033 Harness, Controls (Refrigerator)

FREEZER LINER PARTS

For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11


(White)

(Black)

(Stainless Steel)

(Bisque)

(Satina)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11
(White) (Black) (Stainless Steel) (Bisque) (Satina)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|------------------------------------|
| 1 | | Liner (Not A Serviceable Part) |
| 2 | 67001291 | Gasket, Foam |
| 3 | 12002497 | Gear (Includes RH & LH) |
| 4 | 67003905 | Cover, Light |
| 5 | 67004261 | Shaft |
| 6 | Y12570701 | Socket, Light |
| 7 | 12002497 | Gear (Includes LH & RH) |
| 8 | 67006737 | Screw |
| 9 | A0282812 | Bulb, Light |
| 10 | 67001035 | Housing, Frz. Light |
| 11 | 67005872 | Cover, Evaporator |
| 12 | 67006425 | Screw |
| 13 | | Bracket, Door |
| | W10122147 | Left |
| | W10122148 | Right |
| 14 | 67003906 | Housing, Lighting |
| 15 | W10167028 | Clip, Evap. Motor |
| 16 | 67005653 | Switch, Light |
| 17 | 67006530 | Screw |
| 18 | | Bracket, Basket |
| | W10187668 | Left |
| | W10187667 | Right |
| 19 | W10120018 | Slide, Drawer (2) |
| 20 | 67001776 | Gasket, Bottom |
| 21 | | Bracket, Slide |
| | W10128118 | Left |
| | W10128119 | Right |
| 22 | W10175909 | Cover, Fan Shroud |
| 23 | W10167023 | Shroud, Evap. Fan |
| 24 | 2169142 | Fan, Evaporator |
| 25 | W10121318 | Grommet |
| 26 | 67003636 | Motor, Evaporator |
| 27 | D7753903 | Funnel, Drain (Incl. # 28 & 29) |
| 28 | M0500703 | Seal |
| 29 | B8381501 | Gasket |
| 30 | 12002355 | Thermistor |
| 31 | 67003924 | Cover, Thermistor |
| 32 | 67006406 | Screw |

Following Parts Not Illustrated

67006095 Harness, Lights
(Freezer)

REFRIGERATOR DOOR PARTS

For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11


(White)

(Black)

(Stainless Steel)

(Bisque)

(Satina)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS


For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11
 (White) (Black) (Stainless Steel) (Bisque) (Satina)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|--------------------------------------|
| 1 | | Refrigerator Door (w/ Insulation) |
| | 67004777 | White |
| | 67004775 | Black |
| | W10187674 | Stainless Steel |
| | 67004776 | Bisque |
| | W10187675 | Satina |
| 2 | | Plug, Vent |
| | 10712401 | White |
| | 67004838 | Black |
| 3 | 67003819 | Door, Compartment |
| 4 | 67001279 | Tray, Dairy |
| 5 | 67003777 | Bucket (2) (Medium) |
| 6 | | Plug, Handle Hole |
| | 67001130 | White |
| | 67001131 | Black |
| | 12246606 | Stainless Steel |
| | 67001132 | Bisque |
| 7 | 67002684 | Nameplate |
| 8 | | Gasket, Door Magnetic |
| | W10130893 | White |
| | W10131327 | Black |
| 9 | | Handle, Door |
| | 2254600W | White |
| | 2254600B | Black |
| | 2254600S | Stainless Steel |
| | 2254600T | Bisque |
| 10 | 67006901 | Screw |
| 11 | | Closure, Door |
| | 67003638 | White |
| | 67003639 | Black |
| 12 | 67006113 | Mount, Handle |
| 13 | | Bushing |
| | 67004977 | White |
| | 67004978 | Black |
| 14 | 67001748 | Trim, Door Shelf |
| 15 | 67006287 | Screw |
| 16 | | Stop, Door |
| | 67003779 | White |
| | 67003781 | Bisque |
| | 67003780 | Black |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11
(White) (Black) (Stainless Steel) (Bisque) (Satina)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS


For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11
 (White) (Black) (Stainless Steel) (Bisque) (Satina)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|---------------------------------|
| 1 | | Freezer Door (w/ Insulation) |
| | W10168778 | White |
| | W10168779 | Black |
| | W10170543 | Stainless Steel |
| | W10187676 | Satina |
| | W10188475 | Bisque |
| 2 | | Handle, Door |
| | 2254600W | White |
| | 2254600B | Black |
| | 2254600S | Stainless Steel |
| | 2254600T | Bisque |
| 3 | 67006113 | Mount, Handle |
| 4 | | Gasket, Door |
| | W10130894 | White |
| | W10130587 | Black |
| 5 | 67006901 | Screw |
| 6 | | Plug, Vent (2) |
| | 10712401 | White |
| | 67004838 | Black |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11
(White) (Black) (Stainless Steel) (Bisque) (Satina)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11

(White)

(Black)

(Stainless Steel)

(Bisque)

(Satina)

| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|--------------------------------|
| 1 | 67006433 | Screw |
| 2 | W10162928 | Blade, Fan |
| 3 | 67005744 | Basepan |
| 4 | 67006425 | Screw |
| 5 | 67004954 | Screw |
| 6 | W10130129 | Compressor |
| 7 | W10119856 | Harness, Evap. Heater |
| 8 | 67004713 | Drain Pan |
| 9 | 61004743 | Grommet (3) |
| 10 | 67001794 | Evaporator Heater |
| 11 | 2164017 | Capacitor (See Item #12) |
| 12 | W10136414 | Start-Dev (Capacitor Incl.) |
| 13 | 61003210 | Gasket |
| 14 | W10165425 | Thermostat |
| 15 | W10137529 | Grommet (4) |
| 16 | W10158508 | Shroud, Condenser |
| 17 | W10136415 | Clip, Capacitor |
| 18 | 67006132 | Condenser |
| 19 | W10167036 | Tube, Discharge |
| 20 | 67001080 | Tray, Drip |
| 21 | 10623002 | Clip, Evaporator |
| 22 | 12001919 | Evaporator |

| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|---|
| 23 | | Dam |
| | 67001084 | Right Side |
| | 67001083 | Left Side |
| 24 | 67004432 | Motor, Fan |
| 25 | 10428101 | Clip, Heater |
| 26 | W10188474 | Harness, Unit (Includes Cord) |
| 27 | B2150504 | Drier (Service) |
| 28 | 10547003 | Clip, Drier (Includes Items 11, 12, 17, 27 & 35) |
| 29 | 67004953 | Bracket, Condenser |
| 30 | W10169124 | Grommet |
| 31 | 67006432 | Screw |
| 32 | 67006573 | Screw (6) |
| 33 | 67006737 | Screw |
| 34 | 67005680 | Grommet (2) |
| 35 | 67005491 | Block, Condenser |
| 36 | 67006434 | Axle, Roller |
| 37 | 67005149 | Roller |

| Illus. No. | Part No. | DESCRIPTION |
|--|----------|--------------------------|
| Following Parts Not Illustrated and Optional Parts Not Included | | |
| | 978025 | Valve, Access (1/4") |
| | 978026 | Valve, Access (5/16") |
| | 978027 | Valve, Access (3/8") |
| | 978028 | Valve, Access (1/2") |
| | 978029 | Valve, Access (5/8") |
| | 978030 | Valve, Access (3/4") |
| | 876764 | Valve, Access (3/16") |
| REFRIGERANT CHARGE | | |
| | | 5.00 Ozs. (R-134A) |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11


(White)

(Black)

(Stainless Steel)

(Bisque)

(Satina)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

SHELF PARTS

For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11
 (White) (Black) (Stainless Steel) (Bisque) (Satina)

| Illus. No. | Part No. | DESCRIPTION |
|---------------|-------------|----------------------------|
| 1 | 67001317 | Ladder, Side |
| 2 | 67006400 | Screw (6) |
| 3 | 67001073 | Ladder, Center |
| 4 | 67006360 | Screw (2) |
| 6 | 12463302 | Shelf, Glide (3) |
| 7 | 67006878 | Glass (2) |
| 8 | 67001056 | Frame, Crisper |
| 9 | 67001289 | Rack, Can |
| 10 | 67005864 | Slide, Humidity Control |
| 11 | | Bracket, Glide |
| | 67001053 | Right |
| | 67001054 | Left |
| 12 | 67006400 | Screw |
| 13 | 67001059 | Support, Frame (2) |
| 14 | 67003935 | Trim, Crisper |
| 15 | 67002633 | Pan, Crisper (2) |
| 16 | 67004986 | Basket, Freezer (Upper) |
| 17 | 67001716 | Hook, Ladder |
| 18 | 67004127 | Divider, Upper Basket |
| 19 | 67006608 | Screw |
| 20 | 67006024 | Basket, Freezer (Lower) |
| 21 | 67006644 | Divider, Lower Basket |
| 22 | 67006626 | Screw (4) |
| 23 | 67001057 | Rail, Center |
| 24 | 67001720 | Brace, Pantry |
| 25 | 67002373 | Shelf |
| 26 | 67007066 | Drawer, Pantry |
| 27 | 67001719 | Track, Pantry |
| 28 | | Support, Pantry |
| | 67001722 | Right |
| | 67001721 | Left |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11


(White)

(Black)

(Stainless Steel)

(Bisque)

(Satina)



| Illus. No. | Part No. | DESCRIPTION |
|------------|----------|--|
| 1 | | Mold & Heater Assembly (Not Available Order D7824706Q) |
| 2 | 67004028 | Arm, Shutoff |
| 3 | 95100-1 | Cup, Fill |
| 4 | 95101-1 | Ejector |
| 5 | 95102-1 | Ice Stripper |
| 6 | 95103-1 | Support & Motor Assembly |
| 7 | 95104-1 | Retainer, Thermostat |
| 8 | | Thermostat (Not Available Order D7824706Q) |

| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|---|
| 9 | 95106-1 | Screw (4) |
| 10 | 67001255 | Pan, Ice |
| 11 | 67004101 | Bracket, Tube Support |
| 12 | 67006531 | Valve, Water Inlet |
| 13 | A3223101 | Insert, Tube |
| 14 | B5705307 | Tubing, Plastic |
| 15 | W10146389 | Harness, Icemaker |
| 16 | 95107-1 | Bracket |
| 17 | 67006662 | Screw |
| 18 | 67004710 | Cover |
| 19 | | Module Assembly (Not Available Order D7824706Q) |

| Illus. No. | Part No. | DESCRIPTION |
|------------|-----------|-------------------|
| 20 | 67006287 | Screw |
| 21 | A1055105 | Spring |
| 22 | 67003753 | Valve, Inlet |
| 23 | B5705323 | Tube, Plastic |
| 24 | M0753001 | Nut |
| 25 | 67005603 | Funnel, Fill Tube |
| 100 | W10122519 | Complete Icemaker |

Following Parts Not Illustrated

18001005 Icemaker Install Kit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS (NOT INCLUDED)

For Models: GB2SHTXTQ11, GB2SHTXTB11, GB2SHTXTS11, GB2SHTXTT11, GB2SHTXTL11
(White) (Black) (Stainless Steel) (Bisque) (Satina)

| Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION | Illus. No. | Part No. | DESCRIPTION |
|---|----------|---------------|-----------------------------------|----------|---|---|-----------|--------------------------|
| <u>PAINT, TOUCH-UP (1/2oz.)</u> | | | <u>PAINT, BULK (1 qt.)</u> | | | <u>TORX SCREW WRENCH</u> | | |
| | 72017 | White | | 799344 | White (Uncut) | | 1117510 | Torx Key |
| | 72032 | Black | | 799340 | Black (Uncut) | | | |
| <u>PAINT, PRESSURIZED SPRAY (12 oz.)</u> | | | <u>Miscellaneous</u> | | | <u>ICE MAKER FIELD INSTALLABLE</u> | | |
| | *350930 | White | | 212643 | Sealer, Gum (4 Feet) | | D7824706Q | Complete Icemaker |
| | *350939 | Black | | 479502 | Tape, Vinyl (3/4 x 108") | | | |
| | *350942 | Primer, White | | 505587 | Sealer, Mastic (1 Qt.) | | | |
| * Important: The spray paint is not to be used where the paint may make contact with the door gaskets. | | | | 503695 | Cork, Sealer (1/4 Pound) | | | |
| | | | | 542638 | Grease, Silicone (1/2 Oz.) | | | |
| | | | | 542639 | Cement, Alumilastic (1-1/4 Oz.) | | | |
| | | | | 799833 | Kit, Evaporator Repair (Aluminum Epoxy) | | | |
| | | | | 833938 | Kit, Terminal Connector | | | |
| | | | | | | | | |
| | | | | | | <u>ACCESSORIES</u> | | |
| | | | | | | | 31462 | Cleaner, Stainless Steel |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST